

Yadong Vehicle Spare Parts Group
 USD and EURO account: YADONG INDUSTRY LIMITED
 Xinyuanguoji, Fangzhuang, Beijing100078 China
 tel:+86-10-52429581
 +8613466609615
 FAX:+86-10-52818138
 E-Mail: zhao.shengbin@autoyadong.com
 yadongbrakemarket@gmail.com
 website: www.autoyadong.com



FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME
FBS234	SHOES BRAKE LINING	FBS546	SHOES BRAKE LINING	FBS572	SHOES BRAKE LINING
FBS617	SHOES BRAKE LINING	FBS625	SHOES BRAKE LINING	FCV 987	FERODO BRAKE PAD
FCV1042	FERODO BRAKE PAD	FCV1043	FERODO BRAKE PAD	FCV1047B	FERODO BRAKE PAD
FCV1102	FERODO BRAKE PAD	FCV1126	FERODO BRAKE PAD	FCV1159	FERODO BRAKE PAD
FCV1277BFE	FERODO BRAKE PAD	FCV1313	FERODO BRAKE PAD	FCV1315	FERODO BRAKE PAD
FCV1367B	FERODO BRAKE PAD	FCV1389	FERODO BRAKE PAD	FCV1390	FERODO BRAKE PAD
FCV1405	FERODO BRAKE PAD	FCV1578B	FERODO BRAKE PAD	FCV1825B	FERODO BRAKE PAD
FCV1855BFE	FERODO BRAKE PAD	FCV239	FERODO BRAKE PAD	FCV523	FERODO BRAKE PAD
FCV627	FERODO BRAKE PAD	FCV733	FERODO BRAKE PAD	FCV760B	FERODO BRAKE PAD
FCV769	FERODO BRAKE PAD	FCV770	FERODO BRAKE PAD	FCV773	FERODO BRAKE PAD
FCV791	FERODO BRAKE PAD	FCV792	FERODO BRAKE PAD	FCV793	FERODO BRAKE PAD
FDB 164	FERODO BRAKE PAD	FDB 1672	FERODO BRAKE PAD	FDB 857	FERODO BRAKE PAD
FDB 1793	FERODO BRAKE PAD	FDB 210	FERODO BRAKE PAD	FDB 978	FERODO BRAKE PAD
FDB100	FERODO BRAKE PAD	FDB1000	FERODO BRAKE PAD	FDB1001	FERODO BRAKE PAD
FDB1002	FERODO BRAKE PAD	FDB1003	FERODO BRAKE PAD	FDB1009	FERODO BRAKE PAD
FDB1011	FERODO BRAKE PAD	FDB1012	FERODO BRAKE PAD	FDB1013	FERODO BRAKE PAD
FDB1014	FERODO BRAKE PAD	FDB1015	FERODO BRAKE PAD	FDB1016	FERODO BRAKE PAD
FDB1017	FERODO BRAKE PAD	FDB1018	FERODO BRAKE PAD	FDB1019	FERODO BRAKE PAD
FDB102	FERODO BRAKE PAD	FDB1020	FERODO BRAKE PAD	FDB1021	FERODO BRAKE PAD
FDB1024	FERODO BRAKE PAD	FDB1025	FERODO BRAKE PAD	FDB1029	FERODO BRAKE PAD
FDB103	FERODO BRAKE PAD	FDB1030	FERODO BRAKE PAD	FDB1034	FERODO BRAKE PAD
FDB1035	FERODO BRAKE PAD	FDB1036	FERODO BRAKE PAD	FDB1037	FERODO BRAKE PAD
FDB1038	FERODO BRAKE PAD	FDB1039	FERODO BRAKE PAD	FDB1040	FERODO BRAKE PAD
FDB1044	FERODO BRAKE PAD	FDB1045	FERODO BRAKE PAD	FDB1049	FERODO BRAKE PAD
FDB105	FERODO BRAKE PAD	FDB1050	FERODO BRAKE PAD	FDB1052	FERODO BRAKE PAD
FDB1054	FERODO BRAKE PAD	FDB1055	FERODO BRAKE PAD	FDB1056	FERODO BRAKE PAD
FDB106	FERODO BRAKE PAD	FDB1062	FERODO BRAKE PAD	FDB1063	FERODO BRAKE PAD
FDB1066	FERODO BRAKE PAD	FDB1067	FERODO BRAKE PAD	FDB1068	FERODO BRAKE PAD
FDB1069	FERODO BRAKE PAD	FDB1070	FERODO BRAKE PAD	FDB1072	FERODO BRAKE PAD
FDB1073	FERODO BRAKE PAD	FDB1075	FERODO BRAKE PAD	FDB1081	FERODO BRAKE PAD
FDB1082	FERODO BRAKE PAD	FDB1083	FERODO BRAKE PAD	FDB1091	FERODO BRAKE PAD
FDB1092	FERODO BRAKE PAD	FDB1093	FERODO BRAKE PAD	FDB1094	FERODO BRAKE PAD
FDB1095	FERODO BRAKE PAD	FDB1096	FERODO BRAKE PAD	FDB1097	FERODO BRAKE PAD
FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME
FDB1098	FERODO BRAKE PAD	FDB1099	FERODO BRAKE PAD	FDB11	FERODO BRAKE PAD
FDB1100	FERODO BRAKE PAD	FDB1101	FERODO BRAKE PAD	FDB1103	FERODO BRAKE PAD
FDB1108	FERODO BRAKE PAD	FDB1109	FERODO BRAKE PAD	FDB1112	FERODO BRAKE PAD
FDB1113	FERODO BRAKE PAD	FDB1114	FERODO BRAKE PAD	FDB1116	FERODO BRAKE PAD
FDB1117	FERODO BRAKE PAD	FDB1124	FERODO BRAKE PAD	FDB1125	FERODO BRAKE PAD

FSL1112	FERODO BRAKE PAD	FSL1132	FERODO BRAKE PAD	FSL1135	FERODO BRAKE PAD
FSL1163	FERODO BRAKE PAD	FSL1167	FERODO BRAKE PAD	FSL1276	FERODO BRAKE PAD
FSL1291	FERODO BRAKE PAD	FSL1293	FERODO BRAKE PAD	FSL1295	FERODO BRAKE PAD
FSL1300	FERODO BRAKE PAD	FSL1318	FERODO BRAKE PAD	FSL1319	FERODO BRAKE PAD
FSL1338	FERODO BRAKE PAD	FSL1339	FERODO BRAKE PAD	FSL1382	FERODO BRAKE PAD
FSL1391	FERODO BRAKE PAD	FSL1393	FERODO BRAKE PAD	FSL1394	FERODO BRAKE PAD
FSL1399	FERODO BRAKE PAD	FSL142	FERODO BRAKE PAD	FSL1420	FERODO BRAKE PAD
FSL1423	FERODO BRAKE PAD	FSL1424	FERODO BRAKE PAD	FSL1425	FERODO BRAKE PAD
FSL1463	FERODO BRAKE PAD	FSL1473	FERODO BRAKE PAD	FSL1480	FERODO BRAKE PAD
FSL1484	FERODO BRAKE PAD	FSL1519	FERODO BRAKE PAD	FSL1520	FERODO BRAKE PAD
FSL1573	FERODO BRAKE PAD	FSL1636	FERODO BRAKE PAD	FSL1641	FERODO BRAKE PAD
FSL175	FERODO BRAKE PAD	FSL212	FERODO BRAKE PAD	FSL276	FERODO BRAKE PAD
FSL308	FERODO BRAKE PAD	FSL346	FERODO BRAKE PAD	FSL392	FERODO BRAKE PAD
FSL406	FERODO BRAKE PAD	FSL408	FERODO BRAKE PAD	FSL435	FERODO BRAKE PAD
FSL450	FERODO BRAKE PAD	FSL471	FERODO BRAKE PAD	FSL517	FERODO BRAKE PAD
FSL519	FERODO BRAKE PAD	FSL520	FERODO BRAKE PAD	FSL524	FERODO BRAKE PAD
FSL540	FERODO BRAKE PAD	FSL579	FERODO BRAKE PAD	FSL584	FERODO BRAKE PAD
FSL586	FERODO BRAKE PAD	FSL589	FERODO BRAKE PAD	FSL590	FERODO BRAKE PAD
FSL597	FERODO BRAKE PAD	FSL598	FERODO BRAKE PAD	FSL609	FERODO BRAKE PAD
FSL660	FERODO BRAKE PAD	FSL686	FERODO BRAKE PAD	FSL700	FERODO BRAKE PAD
FSL701	FERODO BRAKE PAD	FSL712	FERODO BRAKE PAD	FSL715	FERODO BRAKE PAD
FSL722	FERODO BRAKE PAD	FSL763	FERODO BRAKE PAD	FSL774	FERODO BRAKE PAD
FSL775	FERODO BRAKE PAD	FSL785	FERODO BRAKE PAD	FSL790	FERODO BRAKE PAD
FSL797	FERODO BRAKE PAD	FSL833	FERODO BRAKE PAD	FSL874	FERODO BRAKE PAD
FSL925	FERODO BRAKE PAD	FSL929	FERODO BRAKE PAD	FSL931	FERODO BRAKE PAD
FSL950	FERODO BRAKE PAD	FSL970	FERODO BRAKE PAD	FVR1000	FERODO BRAKE PAD
FVR1002	FERODO BRAKE PAD	FVR1014	FERODO BRAKE PAD	FVR1038	FERODO BRAKE PAD
FVR1039	FERODO BRAKE PAD	FVR1043	FERODO BRAKE PAD	FVR1044	FERODO BRAKE PAD
FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME
FVR1045	FERODO BRAKE PAD	FVR1102	FERODO BRAKE PAD	FVR1131	FERODO BRAKE PAD
FVR1132	FERODO BRAKE PAD	FVR1163	FERODO BRAKE PAD	FVR129	FERODO BRAKE PAD
FVR1292	FERODO BRAKE PAD	FVR1304	FERODO BRAKE PAD	FVR1305	FERODO BRAKE PAD
FVR1306	FERODO BRAKE PAD	FVR1315	FERODO BRAKE PAD	FVR1338	FERODO BRAKE PAD
FVR1339	FERODO BRAKE PAD	FVR1352	FERODO BRAKE PAD	FVR1353	FERODO BRAKE PAD
FVR1381	FERODO BRAKE PAD	FVR1390	FERODO BRAKE PAD	FVR1396	FERODO BRAKE PAD
FVR1397	FERODO BRAKE PAD	FVR1405	FERODO BRAKE PAD	FVR1452	FERODO BRAKE PAD
FVR1453	FERODO BRAKE PAD	FVR1461	FERODO BRAKE PAD	FVR1478	FERODO BRAKE PAD
FVR1479	FERODO BRAKE PAD	FVR1480	FERODO BRAKE PAD	FVR1482	FERODO BRAKE PAD
FVR1484	FERODO BRAKE PAD	FVR1492	FERODO BRAKE PAD	FVR1493	FERODO BRAKE PAD
FVR1494	FERODO BRAKE PAD	FVR1497	FERODO BRAKE PAD	FVR1498	FERODO BRAKE PAD
FVR1515	FERODO BRAKE PAD	FVR1516	FERODO BRAKE PAD	FVR1518	FERODO BRAKE PAD
FVR1519	FERODO BRAKE PAD	FVR1568	FERODO BRAKE PAD	FVR1642	FERODO BRAKE PAD
FVR1644	FERODO BRAKE PAD	FVR1701	FERODO BRAKE PAD	FVR1777	FERODO BRAKE PAD
FVR1778	FERODO BRAKE PAD	FVR1779	FERODO BRAKE PAD	FVR1780	FERODO BRAKE PAD
FVR179	FERODO BRAKE PAD	FVR1927	FERODO BRAKE PAD	FVR1929	FERODO BRAKE PAD
FVR215	FERODO BRAKE PAD	FVR239	FERODO BRAKE PAD	FVR287	FERODO BRAKE PAD
FVR302	FERODO BRAKE PAD	FVR321	FERODO BRAKE PAD	FVR369	FERODO BRAKE PAD
FVR377	FERODO BRAKE PAD	FVR414	FERODO BRAKE PAD	FVR418	FERODO BRAKE PAD
FVR450	FERODO BRAKE PAD	FVR492	FERODO BRAKE PAD	FVR501	FERODO BRAKE PAD
FVR505	FERODO BRAKE PAD	FVR510	FERODO BRAKE PAD	FVR511	FERODO BRAKE PAD
FVR516	FERODO BRAKE PAD	FVR517	FERODO BRAKE PAD	FVR543	FERODO BRAKE PAD

FVR547	FERODO BRAKE PAD	FVR549	FERODO BRAKE PAD	FVR626	FERODO BRAKE PAD
FVR641	FERODO BRAKE PAD	FVR655	FERODO BRAKE PAD	FVR656	FERODO BRAKE PAD
FVR690	FERODO BRAKE PAD	FVR700	FERODO BRAKE PAD	FVR701	FERODO BRAKE PAD
FVR713	FERODO BRAKE PAD	FVR722	FERODO BRAKE PAD	FVR752	FERODO BRAKE PAD
FVR757	FERODO BRAKE PAD	FVR785	FERODO BRAKE PAD	FVR791	FERODO BRAKE PAD
FVR792	FERODO BRAKE PAD	FVR793	FERODO BRAKE PAD	FVR805	FERODO BRAKE PAD
FVR829	FERODO BRAKE PAD	FVR833	FERODO BRAKE PAD	FVR836	FERODO BRAKE PAD
FVR839	FERODO BRAKE PAD	FVR84	FERODO BRAKE PAD	FVR852	FERODO BRAKE PAD
FVR886	FERODO BRAKE PAD	FVR941	FERODO BRAKE PAD	FVR949	FERODO BRAKE PAD
FVR967	FERODO BRAKE PAD	FVR968	FERODO BRAKE PAD	FVR970	FERODO BRAKE PAD
KDF048	SHOES BRAKE LINING	TAR1000	FERODO BRAKE PAD	TAR1011	FERODO BRAKE PAD
FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME	FERODO NO.S	PRODUCT NAME
TAR1015	FERODO BRAKE PAD	TAR1045	FERODO BRAKE PAD	TAR1054	FERODO BRAKE PAD
TAR1055	FERODO BRAKE PAD	TAR1062	FERODO BRAKE PAD	TAR1072	FERODO BRAKE PAD
TAR1082	FERODO BRAKE PAD	TAR1083	FERODO BRAKE PAD	TAR1112	FERODO BRAKE PAD
TAR1132	FERODO BRAKE PAD	TAR1135	FERODO BRAKE PAD	TAR1163	FERODO BRAKE PAD
TAR1167	FERODO BRAKE PAD	TAR1276	FERODO BRAKE PAD	TAR1291	FERODO BRAKE PAD
TAR1293	FERODO BRAKE PAD	TAR1295	FERODO BRAKE PAD	TAR1300	FERODO BRAKE PAD
TAR1318	FERODO BRAKE PAD	TAR1319	FERODO BRAKE PAD	TAR1338	FERODO BRAKE PAD
TAR1339	FERODO BRAKE PAD	TAR1391	FERODO BRAKE PAD	TAR1393	FERODO BRAKE PAD
TAR1394	FERODO BRAKE PAD	TAR1399	FERODO BRAKE PAD	TAR142	FERODO BRAKE PAD
TAR1420	FERODO BRAKE PAD	TAR1423	FERODO BRAKE PAD	TAR1424	FERODO BRAKE PAD
TAR1425	FERODO BRAKE PAD	TAR1463	FERODO BRAKE PAD	TAR1520	FERODO BRAKE PAD
TAR175	FERODO BRAKE PAD	TAR212	FERODO BRAKE PAD	TAR222	FERODO BRAKE PAD
TAR241	FERODO BRAKE PAD	TAR243	FERODO BRAKE PAD	TAR276	FERODO BRAKE PAD
TAR308	FERODO BRAKE PAD	TAR346	FERODO BRAKE PAD	TAR392	FERODO BRAKE PAD
TAR406	FERODO BRAKE PAD	TAR408	FERODO BRAKE PAD	TAR415	FERODO BRAKE PAD
TAR419	FERODO BRAKE PAD	TAR435	FERODO BRAKE PAD	TAR450	FERODO BRAKE PAD
TAR471	FERODO BRAKE PAD	TAR517	FERODO BRAKE PAD	TAR519	FERODO BRAKE PAD
TAR520	FERODO BRAKE PAD	TAR524	FERODO BRAKE PAD	TAR540	FERODO BRAKE PAD
TAR541	FERODO BRAKE PAD	TAR562	FERODO BRAKE PAD	TAR578	FERODO BRAKE PAD
TAR579	FERODO BRAKE PAD	TAR584	FERODO BRAKE PAD	TAR586	FERODO BRAKE PAD
TAR589	FERODO BRAKE PAD	TAR590	FERODO BRAKE PAD	TAR597	FERODO BRAKE PAD
TAR598	FERODO BRAKE PAD	TAR609	FERODO BRAKE PAD	TAR646	FERODO BRAKE PAD
TAR660	FERODO BRAKE PAD	TAR686	FERODO BRAKE PAD	TAR700	FERODO BRAKE PAD
TAR701	FERODO BRAKE PAD	TAR708	FERODO BRAKE PAD	TAR712	FERODO BRAKE PAD
TAR715	FERODO BRAKE PAD	TAR722	FERODO BRAKE PAD	TAR763	FERODO BRAKE PAD
TAR774	FERODO BRAKE PAD	TAR775	FERODO BRAKE PAD	TAR785	FERODO BRAKE PAD
TAR790	FERODO BRAKE PAD	TAR797	FERODO BRAKE PAD	TAR833	FERODO BRAKE PAD
TAR846	FERODO BRAKE PAD	TAR854	FERODO BRAKE PAD	TAR868	FERODO BRAKE PAD
TAR874	FERODO BRAKE PAD	TAR925	FERODO BRAKE PAD	TAR929	FERODO BRAKE PAD
TAR931	FERODO BRAKE PAD	TAR950	FERODO BRAKE PAD	TAR951	FERODO BRAKE PAD
TAR954	FERODO BRAKE PAD	TAR970	FERODO BRAKE PAD	TAR986	FERODO BRAKE PAD